



1	CONTACT
2	OUT3
3	SERIAL_CLK
4	GND
5	SERIAL_DATA
6	GND
7	SERIAL_STT
8	GND
9	VSYNC_IN
10	GND
11	LOCAL_EN
12	GND
13	OUT1
14	GND
15	EXT_OP
16	GND
17	SW_RESET
18	GND
19	GND
20	OUT2

PJ730			
1	POWER_KEY		
2	ADC_IN2		
3	GND		
4	ADC_IN1		

CN730			
1	POWER_KEY		
2	ADC_IN2		
3	GND		
4	ADC_IN1		

CN651	
1	VCC_LCD
2	VCC_LCD
3	VCC_LCD
4	VCC_LCD
5	VCC_LCD
6	GND
7	GND
8	GND
9	GND
10	GND
11	TE2+
12	TE2-
13	TD2+
14	TD2-
15	GND
16	TCLK2+
17	TCLK2-
18	GND
19	TC2+
20	TC2-
21	TB2+
22	TB2-
23	TA2+
24	TA2-
25	GND
26	GND
27	TE1+
28	TE1-
29	TD1+
30	TD1-
31	GND
32	TCLK1+
33	TCLK1-
34	GND
35	TC1+
36	TC1-
37	TB1+
38	TB1-
39	TA1+
40	TA1-
41	LVDS T1_GND
42	DLC0
43	DLC1
44	BL_PWM_OUT
45	LVDS_SEL
46	LCLDIM_ONOFF
47	SCAN_ONOFF
48	NC
49	LVDS T1_GND
50	LVDS T1_GND
51	LVDS T1_GND
Shield	COMMON GND

CN652	
1	GND
2	GND
3	TE4+
4	TE4-
5	TD4+
6	TD4-
7	GND
8	TCLK4+
9	TCLK4-
10	GND
11	TC4+
12	TC4-
13	TB4+
14	TB4-
15	TA4+
16	TA4-
17	GND
18	GND
19	TE3+
20	TE3-
21	TD3+
22	TD3-
23	GND
24	TCLK3+
25	TCLK3-
26	GND
27	TC3+
28	TC3-
29	TB3+
30	TB3-
31	TA3+
32	TA3-
33	GND
34	GND
35	TC1+
36	TC1-
37	VCC_LCD
38	VCC_LCD
39	VCC_LCD
40	VCC_LCD
41	VCC_LCD
Shield	COMMON GND

CN653	
7	PWM_SEL
6	GND_INV
5	BL_DET
4	VBR (0V-3.3V)
3	PWM
2	DIM_SW
1	BL_ONOFF

CN710	
3	STOP_FAN
2	GND
1	VCC_FAN

CN91	
8	12V_LCD
7	12V_LCD
6	GND
5	GND
4	POWER_LCD
3	AC_DETECT
2	POWER_SIG
1	POWER_PROTECT

CN90	
14	GND
13	5V1
12	GND
11	12V
10	12V
9	12V
8	GND
7	POWER_TV
6	GND
5	(24V_LNB)
4	18V_AUDIO
3	18V_AUDIO
2	GND_AUDIO
1	GND_AUDIO

CN30	
4	L+_AMP
3	L-_AMP
2	R+_AMP
1	R-_AMP

CN720	
1	VCC_9V_LOGO
2	ON/OFF_LOGO

CN740	
15	HDD_LED
14	PROGRAM_TIMER_O
13	PROGRAM_TIMER_R
12	ON_TIMER
11	STAND_BY_LED
10	POWER_ON_LED
9	3.3_TV
8	GND
7	RGB_SCL
6	OP_IN/RGB_SDA
5	3.3_TV
4	5V1
3	GND
2	IR_OUT
1	RMT_IN

P860	
10	GND_INV
9	GND_INV
8	GND_INV
7	GND_INV
6	GND_INV
5	24V_INV
4	24V_INV
3	24V_INV
2	24V_INV
1	24V_INV

P861	
10	GND_INV
9	GND_INV
8	GND_INV
7	GND_INV
6	GND_INV
5	24V_INV
4	24V_INV
3	24V_INV
2	24V_INV
1	24V_INV

PJ93	
1	GND
2	GND
3	12V
4	12V

PJ91	
1	POWER_PROTECT
2	POWER_SIG
3	AC_DETECT
4	POWER_LCD
5	GND
6	GND
7	12V_LCD
8	12V_LCD

PJ90	
1	GND_AUDIO
2	GND_AUDIO
3	18V_AUDIO
4	18V_AUDIO
5	(24V_LNB)
6	GND
7	POWER_TV
8	GND
9	12V
10	12V
11	12V
12	GND
13	5V1
14	GND

P801A	
NEWTRAL	2
LINE	1

Speaker

Speaker